

THE DRIVE TARGET FOR SYNTHETIC SURFACES

The Drive Target for Synthetic Surfaces has been specially designed to be placed upon these surfaces without any damage to the surface nor material that it may be attached to.

The target remains static by means specially designed hooks that pierce the surface of the material in which each hook is only 1mm thick which penetrates into the playing surface 2mm without damage to the material to which it is be fixed upon. To assist in the stabilization of the target Velcro is also mounted to the underside of the target plate which makes the target static throughout its ordeal. Sticky tape No. RB51 from a hardware store has been proven the best if required which have a color selection also.

When attaching any target to a playing surface whether it be grass or synthetic the correct procedures for this surface should be adhered such as described below.

When setting the target to the playing surface tilt the leading edge forward and draw backwards until the hooks hold then press downwards at the rear of the plate for complete anchorage.

In the process of retrieving the target always slightly raise the rear of the target plate first then push the plate forward for a complete withdrawal of the hooks to ensure no damage to the playing surface will occur.

ABP has a great range of targets designed for both indoor and outdoor synthetic surfaces.

THE DRIVE TARGET For SYNTHETIC SURFACES

